


4. **Eco motion 1800K.** Auto start at sunset, idle at 50 lumens, 500 lumens when triggered by motion sensor for 20 seconds - **Tap four times**, four flashes.
5. **Custom 2700K:** Dimmable 5 levels 500/ 400/ 300/ 200/ 100 lumen. **Tap five times**, five flashes. **Hold to dim.**
6. **Custom 1800K:** Dimmable 5 levels 500/ 400/ 300/ 200/ 100 lumen. **Tap six times**, six flashes. **Hold to dim.**




Warranty

Warranty does not cover misuse or unintentional damages such as water immersion, a fall or drop generating visible scratches or invisible electronic damages inside the module.

YKARY SOLAR BULB

YK221 User Guide



LES JARDINS® | HIGH EFFICIENCY SOLAR LIGHTING

Made on Earth
Powered by the Sun®

www.lesjardins.solar



Congratulations on purchasing this YKARY bulb! Brighter times are ahead for you!

Below are the initial steps to set-up the bulb to suit your needs.

Place the YKARY bulb on a dark flat surface with the **solar panel facing down**.

First step is to **fully charge** your YKARY bulb batteries by **plugging in the provided cable** and attaching the magnetic plug to your product. Yes, this bulb is solar. Charging via the micro USB cable is **only necessary before the first use**. Leave your YKARY bulb charging for **5 hours**. Power source requirement is 5 volts, 2AMP.

Next – **Unlock** device by pressing the control button (☼) for 8 seconds until it blinks once.

Then **press once to unlock**.

It will remain unlocked for **10 minutes** before locking itself again to prevent unwanted changes to your settings. Now you can choose your preference (mode) below and follow the applicable steps. Use the control button (☼) to make your selection.

****IMPORTANT NOTE****

Do not press the button rapidly. Wait for flashes in between each tap of the control button

6 PRESET MODES:

1. **Eco smart 2700K.** Auto start at sunset for 6 hours - **Tap once**, one flash.
2. **Eco smart 1800K.** Auto start at sunset for 6 hours - **Tap twice**, two flashes.
3. **Eco motion 2700K.** Auto start at sunset, idle at 50 lumens, 500 lumens when triggered by motion sensor for 20 seconds - **Tap three times**, three flashes.

